

Chaussure basses microfibres VIGO S2 SRC - SINGER - VIGO



Référence (SKU) : CFG11041

Réf. fournisseur : VIGO



DESCRIPTION

Chaussure basse type Mocassin.

Coloris blanc.

Tige en microfibres. Doublure haute de quartier.

Semelle polyuréthane bi-densité. Embout acier.

Semelle intérieure complète et amovible, antistatique avec système d'amortissement.

Chaussure confortable, souple (sans semelle intercalaire) et légère.

Tige avec traitement imperméable.

Qualité des matériaux et de la confection.

VARIANTES

Réf.	Nom	
CHA50701	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.36	VIGO36
CHA50702	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.37	VIGO37
CHA50703	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.38	VIGO38
CHA50704	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.39	VIGO39
CHA50705	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.40	VIGO40
CHA50706	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.41	VIGO41
CHA50707	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.42	VIGO42
CHA50708	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.43	VIGO43
CHA50709	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.44	VIGO44
CHA50710	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.45	VIGO45
CHA50711	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.46	VIGO46
CHA50712	Chaussure basses microfibres VIGO S2 SRC - SINGER - T.47	VIGO47